

Replace battery:

1.



2.



Assemble on bicycle:

1.



2.



Roll the tire to show the computer working:



Function showing (how to set , pls refer to the manual “adjustment state”) :

